

















## 58.705


### v10

Installation manual/Installatie handleiding  
 Installations-handbuch/Manuel d'installation  
 Manuale d'installazione/Manual de instalación  
 Copyright © 2015–Dataflex International BV













T +31 180 515444  
 F +31 180 518540  
 info@dataflex-int.com  
 www.dataflex-int.com

#### Parts/Onderdelen/Pièces/Teile/Parti/Partes


a  2x	b  1x	c  2x	d  2x	e  2x	f  2x	g  2x	h  10x	i  4x
j  2x	k  2x	l  2x	m  2x	n  6mm 1x	o  5mm 1x	p  3mm 1x		



or/of/oder/ou/o



viewlite<sup>x</sup>



No rights can be derived from this publication/  
Aan deze uitgave kunnen geen rechten worden  
ontleend/Aus dieser Ausgabe können keine  
Rechte abgeleitet werden/Aucun droit ne peut  
découler de cette publication/Dal presente  
documento non deriva alcun diritto/Del  
contenido de esta publicación no podrá  
derivarse ningún derecho